



INSTALLATION INSTRUCTIONS **EN**

ISTRUZIONI D'INSTALLAZIONE **IT**

NOTICE D'INSTALLATION **FR**

**AEI1G30EMX**



---

**Split air conditioner system**  
**Condizionatore d'aria split system**  
**Climatiseur split**

# CONTENTS

EN

1 - Installation site selection.....	4
2 - System wiring diagram .....	4
3 - Wires' size and delayed fuse.....	4
4 - Additional material required for installation (not supplied) .....	5
5 - Operating limits.....	5
6 - Tubing length and elevation difference limits.....	5
7 - Tools required for installation (not supplied) .....	5
8 - Dimensions and weight .....	6
9 - Installation procedure .....	7
10 - Basic functions of the service valves .....	9
11 - Pump Down procedure.....	10
12 - Auto-diagnosis table.....	11
13 - Electrical wiring diagram.....	12
14 - Refrigerant circuit .....	14

## REGULATION (EU) No. 517/2014 - F-GAS

The unit contains R410A, a fluorinated greenhouse gas with a global warming potential (GWP) of 2088. Do not release R410A into the atmosphere.

R410A: 0.81 kg / 1.69 t CO<sub>2</sub> - eq

## PRODUCT INFORMATION

The year of production of this unit is indicated in the Nameplate:

s/n: Y00000RR

Year of production  
example: 0=2020  
1=2021

Serial number

## IMPORTANT!

### Please read before installation

This air conditioning system meets strict safety and operating standards.

For the installer or service person, it is important to install or service the system so that it operates safely and efficiently.

### For safe installation and trouble-free operation, you must:

- Carefully read this instruction booklet before beginning.
- Follow each installation or repair step exactly as shown.
- Observe all local, state and national electrical codes.
- Pay close attention to all warning and caution notices given in this manual.
- The unit must be supplied with a dedicated electrical line.



**WARNING**

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



**CAUTION**

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

These instructions are all you need for most installation sites and maintenance conditions.

If you require help for a special problem, contact our sale/service outlet or your certified dealer for additional instructions.

### In case of improper installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

## SPECIAL PRECAUTIONS

- During installation, connect before the refrigerant system and then the wiring one; proceed in the reverse order when removing the units.

**WARNING****When wiring****EN**

**ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIANS SHOULD ATTEMPT TO WIRE THIS SYSTEM.**

- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked, to ensure the grounding.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring.  
Improper connections and inadequate grounding can cause **accidental injury and death**.
- Ground the unit following local electrical codes.
- The Yellow/Green wire cannot be used for any connection different from the ground connection.
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.
- Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- Do not use multi-core cable when wiring the power supply and control lines. Use separate cables for each type of line.

**When transporting**

Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminium fins on the air conditioner can cut your fingers.

**When installing...****... In a ceiling or wall**

Make sure the ceiling/wall is strong enough to hold the unit-weight. It may be necessary to build a strong wooden or metal frame to provide added support.

**... In a room**

Properly insulate any tubing run inside a room to prevent “sweating”, which can cause dripping and water damage to walls and floors.

**... In moist or uneven locations**

Use a raised concrete base to provide a solid level foundation for the outdoor unit.

This prevents damage and abnormal vibrations.

**... In area with strong winds**

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

**... In a snowy area**

Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

**When connecting refrigerant tubing**

- Observe the information on the tubing length.
- Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them; screw by hand and then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.

**NOTE:**

Depending on the system type, liquid and gas lines may be either narrow or wide. Therefore, to avoid confusion, the refrigerant tubing for your particular model is specified as narrow tube for liquid, wide tube for gas.

**When servicing**

- Turn the power OFF at the main power board before opening the unit to check or repair electrical parts and wiring.
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after the work, remembering to check that no metal scraps or bits of wiring have been left inside the unit being serviced.
- Ventilate the room during the installation or testing the refrigeration system; make sure that, after the installation, no gas leaks are present, because this could produce toxic gas and dangerous if in contact with flames or heat-sources.

## 1 - INSTALLATION SITE SELECTION

EN


### AVOID

- Heat sources, exhaust fans.
- Direct sunlight.
- Damp, humid or uneven locations.
- To make holes in areas where electrical wiring or conduits are located.


### DO

- Choose places as cool as possible and well ventilated.
- use lug bolts or equal to bolt down the unit, reducing vibration and noise.

Provide a solid base for outdoor unit raised from the ground level. Fix unit to base using 4 anchor bolts.



## 2 - SYSTEM WIRING DIAGRAM



DELAYED FUSE

220 - 240 V ~ 50 Hz



Main switch for disconnection from the supply line must have a contact separation in all poles that provides full disconnection under category III overvoltage conditions.

## 3 - WIRES' SIZE AND DELAYED FUSE

A	B	C	Max. electric input	
S (mm <sup>2</sup> )	S (mm <sup>2</sup> )	S (mm <sup>2</sup> )	kW / A	
1,5	0,75	1,5	1,6 / 6,9	10 A

### Supply power wire A:

Multipolar electric wire; the size of the suggested electric wire is showed on the table. The wire must be Mod. H07RN-F (according to CEI 20-19 CENELEC HD 22). Make sure the length of the conductors between the fixing point and the terminals allows the straining of the conductors L, N before that of the grounding.

### Connecting wire B (SHIELDED):

Bipolar electric shielded wire; the size of the suggested electric wire is showed on the table. The wires have not to be lighter than Mod. H05VVC4V5-K (according to CEI 20-20 CENELEC HD21).

### Connecting wire C (with ground conductor):

Multipolar electric wire; the size of the suggested electric wire is showed on the table. The wires have not to be lighter than Mod. H07RN-F (according to CEI 20-19 CENELEC HD22). Make sure the length of the conductors between the fixing point and the terminals allows the straining of the conductors L, N before that of the grounding.

## 4 - ADDITIONAL MATERIAL REQUIRED FOR INSTALLATION (NOT SUPPLIED)

- Deoxidized annealed copper tube for refrigerant tubing connecting the units of the system; it has to be insulated with foamed polyethylene (min. thickness 8mm).

EN

NARROW TUBE		LARGE TUBE	
OUTER DIAMETER	MIN. THICKNESS	OUTER DIAMETER	MIN. THICKNESS
6,35 mm	0,8 mm	9,52 mm	0,8 mm

- PVC pipe for condensate drain pipe (ø int.18mm) in length suitable to let the condensate flow into the outside drainage.
- Anti-freeze oil for flare connections (about 30g.).
- Electric wire: use insulated copper wires of size and length as shown at paragraph "WIRES' SIZE AND DELAYED FUSE".

## 5 - OPERATING LIMITS

### OPERATING LIMITS

#### ■ Cooling Maximum conditions

Outdoor temperature : 43°C D.B.

Room temperature : 32°C D.B. / 23°C W.B.

#### ■ Heating Maximum conditions

Outdoor temperature : 24°C D.B. / 18°C W.B.

Room temperature : 27°C D.B.

#### ■ Cooling Minimum conditions

Outdoor temperature : -15°C D.B.


Room temperature : 10°C D.B. / 6°C W.B.

#### ■ Heating Minimum conditions

Outdoor temperature : -15°C D.B.

Room temperature : 5°C D.B.

## 6 - TUBING LENGTH AND ELEVATION DIFFERENCE LIMITS



TOTAL TUBING LENGTH	TOTAL TUBING LENGTH
AT SHIPMENT (m)	WITH ADDITIONAL REFRIGERANT (m)
7,5	15

### REQUIRED AMOUNT OF ADDITIONAL REFRIGERANT

For tubing 1/4 " - 3/8" = 15g/m

For tubing 1/4 " - 1/2" = 20g/m

For tubing Emix (3/8") = 15g/m

LIMIT OF ELEVATION DIFFERENCE - OUTDOOR UNIT/INDOOR UNIT: 10m (H)

No additional charge of compressor oil is necessary.

## 7 - TOOLS REQUIRED FOR INSTALLATION (NOT SUPPLIED)



- Standard screwdriver
- Phillips head screwdriver
- Knife or wire stripper
- Tape measure
- Level
- Sabre saw or key hole saw

- Hacksaw
- Core bits ø 5
- Hammer
- Drill
- Tube cutter


- Tube flaring tool
- Torque wrench
- Adjustable wrench
- Reamer (for reburrring)
- Hexagonal key

## 8 - DIMENSIONS AND WEIGHT

EN



**Weight:** 35 kg




Unit: mm


## 9 - INSTALLATION PROCEDURE

EN


- A** Minimum operation and maintenance area.




- B** Heat pump version.  
Use, if necessary, the accessories supplied.




- C** Remove the side cover, then connect the power line and interconnecting wires to outdoor unit on the terminal strip and secure them with clamps.




- D** Use insulated copper tube. Cut approximate 30-50 cm. longer than actual distance between units.




- E** Remove burrs at the ends of the copper tubes. Hold the tube end downward and be sure that no dirt falls into the tube.




- F** Insert flare nuts removed from the units, then make a flare at the end of copper tubes.




- G** A good flare has the following characteristics:
- inside surface is glossy and smooth
  - edge is smooth
  - tapered sides are of uniform length.
- Apply refrigerant lubricant to the matching surface of the flare and union before connecting them together.




- I** Insulate tubes leaving connections uncovered for leak test.



- K** Remove caps from service valves of both tubes. Then start vacuum pump and let it run for the time indicated in the table (vacuum 10 mm Hg abs.).




- H** Tighten connections using a spanner and a torque wrench; apply specified torque (see table).



TUBE DIA.	TIGHTENING TORQUE
6,35 mm (1/4")	Approx. 150 – 200 kgcm (15 - 20 Nm)
9,52 mm (3/8")	Approx. 350 – 400 kgcm (30 - 40 Nm)
12,7 mm (1/2")	Approx. 500 – 550 kgcm (50 - 55 Nm)


- J** Air purging of internal unit and refrigerant tubes. Connect the vacuum pump to the outside unit as shown in the figure. Air and moisture have undesirable effects on the refrigerant system.











VACUUM PUMP CAPACITY 100 l/h	
Tubing length: less than 10 m	Tubing length longer than 10 m
10 min. or more	15 min. or more




- L** With vacuum pump still running close the low pressure knob on valve manifold. Then stop vacuum pump. Using an hexagonal key, open the service valve on small tube, then close it after 10 seconds. Check tightness of all joints using liquid soap.



## 10 - BASIC FUNCTIONS OF THE SERVICE VALVES


Action	Narrow tube service valve (2-way)	Wide tube service valve (3-way)
Shipping	CLOSED 	
Operating and test running the air conditioner	OPEN 	
Measuring pressure and gas charging	OPEN 	
Air purging with a vacuum pump	CLOSED 	

\*




The service port on the wide tube service valve uses a Schrader core valve to access the refrigerant system. Therefore, be sure to use a hose connector which has a push-pin inside.

- M** Turn the service valves stem in counterclockwise to fully open the valves. At this point vacuum pump flexible hose can be disconnected. Replace bonnet and flare nut, tighten them to 200 kg/cm with a torque wrench.




- N** Complete insulation of refrigerant tubes; wrap with arming tape. Fix and support tubes with brackets. Seal hole in the wall, if necessary.




## 11 - PUMP DOWN PROCEDURE

Pump down means collecting all refrigerant gas in the system back into the outdoor unit without losing gas. Pump down is used when the unit is to be moved or before servicing the refrigerant circuit.


- A** Connect a valve manifold to the charge port on a wide tube service valve, partially open it (1/4 turn). Let the air purge from the manifold. Fully close the narrow tube service valves all the way.



- B** Turn on the unit's operating switch and start cooling operation. When the low-pressure gauge reading falls to 1 to 0,5 Kg/cm<sup>2</sup>, close the wide tube valves and then quickly turn off the unit.



- C** Remove the valve manifold. At that time, PUMP DOWN has been completed and all refrigerant gas will have been collected in the outdoor unit.



## 12 - AUTO-DIAGNOSIS TABLE



### CAUTION

EN

Disconnect power and wait that all LEDs are OFF before servicing on the electrical box.

X LED OFF

O LED ON

⚡ LED BLINKING

COD.	LEDs ON BOARD					DESCRIPTION
10	X	⚡	X	X	X	CDT PROBE DAMAGED OR NOT CONNECTED
9	X	X	⚡	X	X	OAT PROBE DAMAGED OR NOT CONNECTED
8	X	X	X	⚡	X	OCT PROBE DAMAGED OR NOT CONNECTED
7	X	X	X	X	⚡	COMPRESSOR ERROR
6	⚡	⚡	X	X	X	PCB OVERTEMPERATURE (COMPRESSOR MODULE)
5	X	⚡	⚡	X	X	FAN MOTOR ERROR
4	X	X	⚡	⚡	X	PCB OVERTEMPERATURE (FAN MOTOR MODULE)
3	X	X	X	⚡	⚡	ERROR ON INDOOR UNIT
2	⚡	⚡	⚡	X	X	COMMUNICATION ERROR
1	X	⚡	⚡	⚡	X	PFC PROTECTION
	<b>DL3</b>	<b>DL4</b>	<b>DL5</b>	<b>DL6</b>	<b>DL7</b>	
	O	O	O	O	O	

### LEGENDA

PFC = Power factor corrector (\*)

OCT = Outdoor coil temperature

OAT = Outdoor air temperature

CDT = Compressor discharge temperature


(\*) Meaning

Automatic protection against power supply disturbances and instabilities.

Unit working properly:


O	O	X	X	X	IF AT LEAST ONE INDOOR UNIT IS ON
O	X	X	X	X	IF ALL INDOOR UNITS ARE OFF
<b>DL3</b>	<b>DL4</b>	<b>DL5</b>	<b>DL6</b>	<b>DL7</b>	<b>DESCRIPTION</b>

# 13 - ELECTRICAL WIRING DIAGRAM • SCHEMA ELETTRICO • SCHÉMA ÉLECTRIQUE



COLOURS	EG	I	F	D	E	P
BLK	BLACK	NERO	NOIR	SCHWARZ	NEGRO	PRETO
BLU	BLUE	BLU	BLEU	BLAU	AZUL	AZUL
BRN	BROWN	MARRONE	MARRON	BRAUN	MARRÓN	CASTANHO
GRN / YEL - G / Y	GREEN / YELLOW	VERDE / GIALLO	VERT / JAUNE	GRÜN / GELB	VERDE / AMARILLO	VERDE / AMARELO
GRY	GREY	GRIGIO	GRIS	GRAU	GRIS	CINZENTO
ORG	ORANGE	ARANCIONE	ORANGE	ORANGE	NARANJA	COR-DE-LARANJA
PNK	PINK	ROSA	ROSE	ROSA	ROSA	COR-DE-ROSA
RED	RED	ROSSO	ROUGE	ROT	ROJO	ENCARNADO
VLT	VIOLET	VIOLA	VIOLET	VIOLETT	VIOLETA	VIOLETA
WHT	WHITE	BIANCO	BLANC	WEISS	BLANCO	BRANCO
YEL	YELLOW	GIALLO	JAUNE	GELB	AMARILLO	AMARELO

SYMBOL	EG	IT	FR
<b>A1</b>	CONTROL BOARD	SCHEDA CONTROLLO	CARTE DE COMMANDE
<b>A2</b>	2V EXPANSION BOARD	SCHEDA ESPANSIONE 2V	CARTE D'EXPANSION 2V
<b>A3</b>	4V EXPANSION BOARD	SCHEDA ESPANSIONE 4V	CARTE D'EXPANSION 4V
<b>C</b>	DC BUS 3PH CONDENSER	CONDENSATORE DC BUS 3PH	CONDENSATEUR DC BUS 3PH
<b>CCH1</b>	COMPRESSOR CRANK CASE HEATER	RESISTENZA COMPRESSORE	RESISTANCE DU COMPRESSEUR
<b>CCH2</b>	OIL SEPARATOR CRANK CASE HEATER	RESISTENZA SEPARATORE OLIO	RESISTANCE DU SEPARATEUR D'HUILE
<b>CDT</b>	COMPRESSOR DISCHARGE SENSOR	SENSORE SCARICO COMPRESSORE	CAPTEUR DECHARGE COMPRESSEUR
<b>CM</b>	COMPRESSOR MOTOR	MOTORE COMPRESSORE	MOTEUR DU COMPRESSEUR
<b>EEV</b>	EXPANSION VALVE COIL	BOBINA VALVOLA ESPANSIONE	BOBINE DE LA VANNE D'EXPANSION
<b>EF</b>	EMI FILTER	FITRO EMI	FILTRE EMI
<b>EI</b>	EXTERNAL INDUCTOR	INDUTTORE ESTERNO	INDUCTEUR EXTÉRIEUR
<b>ER</b>	EXTERNAL RESISTANCE	RESISTENZA ESTERNA	RESISTANCE EXTÉRIEURE
<b>F</b>	CONTROL BOARD FUSE	FUSIBILE SCHEDA CONTROLLO	FUSIBLE CARTE DE CONTRÔLE
<b>FM1</b>	UPPER FAN MOTOR	MOTORE VENTOLA SUPERIORE	MOTEUR DU VENTILATEUR SUPÉRIOR
<b>FM2</b>	LOWER FAN MOTOR	MOTORE VENTOLA INFERIORE	MOTEUR DU VENTILATEUR INFÉRIOR
<b>CTST</b>	COMPRESSOR TOP SHELL TEMPERATURE	SENSORE TESTA COMPRESSORE	CAPTEUR DE LA TÊTE DU COMPRESSEUR
<b>INV</b>	INVERSION VALVE COIL	BOBINA VALVOLA INVERSIONE	BOBINE DE LA VANNE RÉVERSIBLE
<b>NTT</b>	NARROW TUBE SENSOR	SENSORE TUBO PICCOLO	CAPTEUR DU PETIT TUBE
<b>WTT</b>	WIDE TUBE SENSOR	SENSORE TUBO GRANDE	CAPTEUR DU GROS TUBE
<b>OAT</b>	OUTDOOR AIR SENSOR	SENSORE ARIA ESTERNO	CAPTEUR AIR EXTÉRIEUR
<b>OCT</b>	OUTDOOR COIL SENSOR	SENSORE BATTERIA ESTERNO	CAPTEUR ECHANGEUR DE CHALEUR EXTÉRIEUR
<b>R</b>	DC BUS 3PH RELAY	RELÉ DC BUS 3PH	RELAIS DC BUS 3PH
<b>RB</b>	3PH RECTIFIER BRIDGE	PONTE RETTIFICATORE 3PH	PONTE REDRESSEUR 3PH
<b>LP</b>	LOW PRESSURE SWITCH	INTERRUTTORE BASSA PRESSIONE	INTERRUPTEUR BASSE PRESSION



<b>SYMBOL</b>	<b>DE</b>	<b>ES</b>	<b>PT</b>
<b>CMP</b>	KOMPRESSOR	COMPRESOR	COMPRESSOR
<b>4WV</b>	4-WEGE RÜCKWÄRTSVENTIL	VÁLVULA INVERSA DE 4 VÍAS	VÁLVULA REVERSA DE 4 VIAS
<b>DEF</b>	ABTAUVENTIL	VÁLVULA DE DESCONGELACIÓN	VÁLVULA DE DESCONGELAÇÃO
<b>EXP</b>	EXPANSIONSVENTIL A-B-C-D-E-F	VÁLVULA DE EXPANSIÓN A-B-C-D-E-F	VÁLVULA DE EXPANSÃO A-B-C-D-E-F
<b>CDT</b>	KOMPRESSOR AUSGABESENSOR	SENSOR DE DESCARGA DEL COMPRESOR	SENSOR DE DESCARGA COMPRESSOR
<b>CHT</b>	SENSOR VOM KOMPRESSORKOPF	SENSOR CABEZA DEL COMPRESOR	SENSOR CABEÇA DO COMPRESSOR
<b>OAT</b>	AUSSENLUFTSENSOR	SENSOR AIRE EXTERIOR	SENSOR AR EXTERIOR
<b>OCT</b>	AUSSEN WARMETAUSCHER SENSOR	SENSOR INTERCAMBIADOR DE CALOR EXTERIOR	SENSOR TROCADOR DE CALOR EXTERIOR
<b>WTT</b>	SENSOR VOM WEITEN ROHR	SENSOR TUBO GRANDE	SENSOR TUBO LARGO
<b>NTT</b>	SENSOR VOM ENGEN ROHR	SENSOR TUBO PEQUEÑO	SENSOR TUBO ESTREITO
<b>LP</b>	NIEDERDRUCK VENTIL	VÁLVULA BAJA PRESIÓN	VÁLVULA BAIXA PRESSÃO
<b>HP</b>	HOCHDRUCK VENTIL	VÁLVULA ALTA PRESIÓN	VÁLVULA ALTA PRESSÃO
<b>LR</b>	FLÜSSIGKEITSEMPFÄNGER	RECEPTOR LIQUIDO	RECEPTOR LÍQUIDO
<b>LS</b>	FLÜSSIGKEITSABSCHEIDER	SEPARADOR DE LIQUIDO	SEPARADOR DO LÍQUIDO
<b>HE</b>	WÄRMETAUSCHER	INTERCAMBIADOR DE CALOR	TROCADOR DE CALOR
<b>OS</b>	ÖLABSCHEIDER	SEPARADOR DE ACEITE	SEPARADOR DE ÓLEO
<b>BP</b>	BY-PASS-VENTIL	VÁLVULA DE PASO	VÁLVULA DE PASSAGEM
<b>E-MIX</b>	KÄLTEMITTELGASANSCHLUSS EMIX-EMIX TANK	CONEXIÓN DE GAS REFRIGERANTE EMIX-EMIX TANK	CONEXÃO DE GÁS REFRIGERANTE EMIX-EMIX TANK

---

**argoclima** s.p.a.

**Società a socio unico**

Via Alfeno Varo, 35 - 25020 Alfianello - BS - Italy

Tel. +39 030 7285700

[www.argoclima.com](http://www.argoclima.com)