

AUTO-DIAGNOSIS TABLE - AQUA UNIT



CAUTION

Disconnect power and wait that all LEDs are OFF before servicing on the electrical box.

DISPLAY	LEDs ON BOARD					DESCRIPTION
101	✱	✱	✱	✱	X	TEST MODE ERROR
100	✱	X	✱	X	✱	COMMUNICATION ERROR WITH EMIX OR 2 ZONE KIT
20	✱	✱	✱	X	✱	COMMUNICATION ERROR WITH DISPLAY
19	✱	X	✱	✱	✱	ERROR ON OUTDOOR UNIT
18	✱	✱	X	X	✱	REFRIGERANT PRESSURE SENSOR NOT CONNECTED
17	X	✱	✱	X	✱	HIGH PRESSURE ERROR
16	✱	X	X	✱	✱	LOW PRESSURE ERROR
11	X	X	X	✱	X	ICT2 SENSOR DAMAGED OR NOT CONNECTED
10	X	X	✱	X	X	ICT1 SENSOR DAMAGED OR NOT CONNECTED
9	X	✱	X	X	X	SWT SENSOR DAMAGED OR NOT CONNECTED
8	✱	X	X	X	X	RWT SENSOR DAMAGED OR NOT CONNECTED
3	X	X	✱	✱	✱	COMMUNICATION ERROR WITH OUTDOOR UNIT
2	X	✱	✱	✱	X	WATER PRESSURE ERROR
1	✱	✱	✱	X	X	NO WATER FLOW
RANK	DL5	DL4	DL3	DL2	DL1	
	O	O	O	O	O	

X LED OFF

O LED ON

✱ LED BLINKING