



EN

ELECTRIC CONVECTION HEATER

Jazz Jazz T



This product is only suitable for well insulated spaces or occasional use.

OPERATING INSTRUCTIONS

Read the instructions carefully before operating the convector or carrying out maintenance operations.
Observe all the safety instructions; failure to observe the instructions may lead to accidents and/or damages.
Store these instructions.

GENERAL SAFETY INFORMATION

- Use this convector only as outlined in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
- This convector is designed for domestic use. It must not be used for commercial or industrial purposes.
- Ensure that the mains voltage complies with that indicated on the convector data plate (220-240V/50Hz).
- This appliance can be used by children aged from 8 years and above and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Remove the convector from its packaging and check that it is in good condition before use. Keep any plastic bags away from children.
- Check the cord and plug before using the convector to ensure that they have not been damaged during transport.
- This convector is not a toy. Children under the age of 3 should be kept away if not supervised.
- Children aged between 3 and 8 must only turn the appliance on / off as long as it has been placed or installed in its normal operating position and that they receive surveillance or instructions regarding the safe use of the appliance and understand it the danger.
- Children between 3 and 8 years of age must not insert the plug, adjust or clean the appliance or carry out maintenance by the user.
- **CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.**
- In order to avoid any danger due to accidental resetting of the thermal cut-off device, this appliance must not be powered by an external switching device, such as a timer, or be connected to a circuit that is regularly supplied with the disarmed by the service.

WARNING: do not use the fan heater with a controller or any other external device that activates the appliance automatically, as there may be a risk of fire if the fan heater is covered or incorrectly positioned.

- Disconnect the mains power when the appliance is not used or for cleaning operations.
- To disconnect the convector, set the selector to 0 and remove the plug from the socket. Pull on the plug only. Do not pull the cord.
- Avoid placing fingers or foreign objects in the air inlet/outlet grilles, as this may lead to electric shock or fire and may damage the convector. To avoid the risk of fire, do not block the grilles or tamper with them in any way while the convector operates.
- Do not use the convector if the cord or plug is damaged. If the power supply cord is damaged, it must be replaced by the manufacturer, dealer or a similarly qualified person so as to avoid any safety risks.
- Do not place any objects on the cord and do not bend it. During operation, the cord must be entirely unwound.
- It is not advisable to use extension cords, as these may overheat and cause the risk of fire. Do not use a single extension cord to operate more than one convector.
- The convector heats up significantly during operation. Risk of burn. To avoid injury, do not allow skin to come into contact with a hot surface. Use the handle to move the convector. Keep flammable materials, such as furniture, cushions, blankets, paper, cloths, curtains and suchlike at least 1 m from the front and back
- Do not immerse the cord, plug or any other element of the panel in water or other liquids.
- Do not touch the plug or convector with wet hands.
- Avoid using the convector in dusty environments or in the presence of flammable vapours (e.g. in workshops or garages).
- Do not place the convector above or near another heat source.

WARNING: AVOID COVERING THE CONVECTOR TO PREVENT IT FROM OVERHEATING.

The symbol below signals the above warning:



- The convector may cause risk of fire if, while in operation, is covered by or comes into contact with **flammable** material including curtains, drapery, blankets, etc. **KEEP THE CONVECTOR AWAY FROM THESE MATERIALS.**
 - Do not insert and avoid accidental insertion of any external objects into the ventilation or discharge outlets as this may lead to electric shock, fire or damage the convector.
 - A convector contains parts that generate arcs or sparks. It must not be used in potentially dangerous areas such as areas at risk of fire or explosion, or areas loaded with chemical substances or humidity.
 - Do not use the convector on soft surfaces such as beds, where the grilles may be covered. Always stand the convector on a flat, stable surface when in operation, in order to prevent it from overturning. Arrange the cord in such a way that the convector and other objects do not rest on it. Do not run the cord under carpets. Do not cover the cord with blankets, carpets or similar materials. Place the cord far away from busy areas, or in a place where it cannot be accidentally pulled-out.
 - This convector cannot be used in bathrooms, laundry rooms, next to a shower, bathtub or swimming pool or in similar indoor environments. Never position the convector where it may fall into a bath or other containers of water.
 - Never position the convector on a wet floor.
 - In any case, the adjustment knobs must never be accessible by anyone in a bath or shower.
 - The heating appliance must not be positioned immediately below a power outlet.
 - The socket must be earthed.
 - Do not allow the electric cord to touch the metal structure of the convector when it is hot or in operation, in order to avoid the high temperatures ruining the cord.
 - Do not operate the convector outdoors. Do not use the convector in front of or near an open window.
- WARNING: do not use the convector with an external controller or any other external device that activates the convector automatically, as there may be a risk of fire if the convector is covered or incorrectly positioned.**


- Upon initial start-up, the convector may emit a slight, harmless smell. This smell is a normal effect of the initial heating up of the internal heating elements, and should not recur later on.
- Do not attempt to repair, disassemble or modify the convector. The convector does not contain parts that can be repaired by the user.
- Turn the switch off and unplug before carrying out any maintenance work or moving the convector. Always unplug from the socket when the convector is not in use.

WARNING: ALWAYS UNPLUG WHEN CARRYING OUT MAINTENANCE WORK OR MOVING THE CONVECTOR.

- Do not place anything on the convector; avoid placing wet garments on the convector.
- Turn the appliance off if unattended in order to avoid accidents.
- If the convector is not used for prolonged periods, disconnect the plug, replace the convector in its box and store it in a dry, ventilated place.
- Ensure that the air inlet /outlet are not close to walls or curtains when the convector is in use, so as to avoid obstructing the convector and hampering its efficiency.
- Should you hear an abnormal noise or detect an unusual smell when using the convector, cease use and unplug immediately.
- Do not expose the elderly or children to a continuous flow of air.
- Do not use the convector if it has been damaged or dropped.
- Do not use if there are visible signs of damage to the heater.
- Use this heater on a horizontal and stable surface, or fix it to the wall, as applicable.
- **WARNING: Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.**
- **WARNING: To reduce the risk of fire, keep textiles, curtains, or any other flammable material a minimum distance of 1 m from the air outlet.**

WARNING: THE ON/OFF SWITCH IS NOT THE ONLY MEANS TO DISCONNECT THE POWER SUPPLY. ALWAYS PULL OUT THE PLUG FROM THE SOCKET IN THE EVENT OF MAINTENANCE OPERATIONS, WHEN MOVING THE PANEL OR WHEN NOT IN USE.

DESCRIPTION OF PARTS



A. Mode setting

- = OFF
- = ECO (750 W)
- = COMFORT (1250W) with turbo
- = SUPER (2000W) with turbo

B. Thermostat

- (min. temperature)
- + (max. temperature)

C. Forced air outlet (Turbo feature)

D. Timer 24h (modèle JAZZ-T)

E. Feet

F. Top grille for air outlet

G. Carrying handles

The convector is available in two different versions:

JAZZ

Mode ECO/COMFORT/SUPER - 750/1250/2000 W - Thermostat and mode selector with turbo


JAZZ T

Mode ECO/COMFORT/SUPER - 750/1250/2000 W – Thermostat and mode selector with turbo and 24h timer.

HOW TO ASSEMBLE THE FEET SUPPLIED

The convector is packed without feet. These must therefore be assembled before using the appliance.

To fix the feet supplied to the convector base, use the 4 screws provided with the unit, taking care to ensure that they are located correctly in the bottom ends of the heater side.



HOW TO USE THE CONVECTOR

Choose a suitable place to position the convector, considering the general safety warnings given in the first part of this manual. Only use this convector in an upright position.

Insert the plug into the electrical socket, ensuring that voltage is compliant with that specified on the convector data plate.

1

Select the desired temperature using the thermostat, turning this knob clockwise: - corresponds to minimum temperature and + to maximum level. The convector will start operating only if the thermostat is above the minimum temperature.




Thermostat

- = (minimum temperature)
+ = (maximum temperature)

2

Then choose the power level desired through the mode selector.



Mode selector

○ = OFF
◻ = ECO (750 W)
☪ = COMFORT (1250W) with turbo
⚡ = SUPER (2000W) with turbo

Room temperature can be regulated by rotating the thermostat clockwise to increase or anticlockwise to decrease temperature.

When turning the panel on, we recommend turning the thermostat knob to maximum: then, when a pleasant room temperature has been obtained, turn the thermostat dial anticlockwise until the light of the active switch goes out. This way the panel will maintain that room temperature constant.

Only for HI FLOOR DESIGN PLUS, please check the timer switch state: if it is on O, the convector can't start operating; if it is on ⌚ the starting time depends on timer setting. If it is on I, the convector can be activated through thermostat and power level selection.


To turn the convector off completely turn the mode selector back to 0 and then rotate the thermostat dial anticlockwise until it clicks off. Unplug the appliance if it will not be used for a while.

OPERATING TIMER (HI FLOOR DESIGN PLUS model)

The model HI FAN DESIGN PLUS is also equipped with 24 hours timer, which has 96 segments, each of which corresponds to 15 minutes of time and allows the lighting and working programming of during the 24 hours.

Red switch on - OFF:
The convector doesn't work or stop working.

Red switch on I - ON:
The convector works continuously, depending only on thermostat regulation.



Red switch on ⌚ - Timer ON:

It allows you to program the convector **on and off timing**. Place the outer ring on the time you want the convector turn on: for example, to set the lighting at 8 p.m. turn the outer ring clockwise until the arrow indicator corresponds to the number 20. Then set the time the heater is required to run by pulling the segments around the outer ring forward appropriate to the running period(s) required. Whereas every rider is 15 minutes, to 1 set 1 hour move out 4 riders between 20 and 21. When set, the heater will operate each day during the times programmed. Note, the heater must **always be plugged into a power socket, the power selector must be in the on position and the thermostat must be suitably set to ensure the heater will come on**. The unit will shut off after the set time. During the set, the operation the unit will still be governed also by the thermostat.

N.B.

If you leave the red switch on ⌚, the convector will turn on automatically every day at the same time, as long as power supply is connected, the power selector is not on 0 and the thermostat is a medium position.

OVERHEATING SAFETY DEVICE

In the event of overheating, an additional fitted safety thermostat protects the heater against overheating and switches it off automatically.

If the device switches itself off, disconnect the main plug from the socket.

The heater is ready for use after a short cooling-off phase (approx. 15 minutes). Plug the mains back into the socket.

If this repeats, first check that the thermostat switch is set correctly or if an object hinders the heating operation.

HOW TO CLEAN THE CONVECTOR

- Always unplug and leave the convector to cool before cleaning.
- Use a damp cloth to clean the convector exterior and remove dust. Leave the casing to dry before using the convector again.
- Do not allow water to enter the convector.
- Do not use benzene, solvents or abrasive compounds to clean the convector, as these may damage the casing.
- Use a vacuum cleaner to remove dust from the air inlet/outlet grilles.
- Ensure that the convector is dry before inserting the plug.
- Do not use metal tools to clean the convector. Any metal fragments that may detach may come into contact with the panel's electrical components and cause a short-circuit.
- In the event of malfunctions or damages, always contact an authorised service centre.

STORING THE CONVECTOR

If the convector is not used for prolonged periods, it must be stored together with this manual in its original packaging, in a cool and dry place. Never put the appliance away when still hot. Always wait for it to cool down.

INFORMATION REQUIREMENTS FOR ELECTRIC LOCAL SPACE HEATERS

Table 2 - Annex II - Ecodesign requirements - Requirements for product information -
COMMISSION REGULATION (EU) 2015/1188 of 28 April 2015 implementing Directive 2009/125/EC of the European Parliament and of the Council with regard to ecodesign requirements for local space heaters

Model identifier(s): JAZZ – JAZZ T					
Item	Symbol	Value	unit	Item	unit
Heat output				Type of heat input, for electric storage local space heaters only (select one)	
Nominal heat output	P_{nom}	1.85	kW	manual heat charge control, with integrated thermostat	[NA]
Minimum heat output (indicative)	P_{min}	0.688	kW	manual heat charge control with room and/or outdoor temperature feedback	[NA]
Maximum continuous heat output	$P_{max,c}$	1.85	kW	electronic heat charge control with room and/or outdoor temperature feedback	[NA]
Auxiliary electricity consumption				fan assisted heat output	
At nominal heat output	e_{lmax}	0.015 (fan motor)	kW	Type of heat output/room temperature control (select one)	
At minimum heat output	e_{lmin}	0.015 (fan motor)	kW	single stage heat output and no room temperature control	[no]
In standby mode	e_{lsb}	0	kW	Two or more manual stages, no room temperature control	[no]
				with mechanic thermostat room temperature control	[no]
				with electronic room temperature control	[no]
				electronic room temperature control plus day timer	[no]
				electronic room temperature control plus week timer	[no]
				Other control options (multiple selections possible)	
				room temperature control, with presence detection	[no]
				room temperature control, with open window detection	[no]
				with distance control option	[no]
				with adaptive start control	[no]
				with working time limitation	[no] JAZZ [yes] JAZZ T
				with black bulb sensor	[no]
Contact details :	ARGOCLIMA SPA - Via A. Varo,35 - Alfianello (BS) - ITALY - www.argoclima.com				

INFORMATION ON PROPER DISPOSAL OF THE APPLIANCE IN COMPLIANCE WITH EUROPEAN DIRECTIVE 2012/19/EU.



When this appliance reaches the end of its useful life, it must not be disposed of together with household waste but must be delivered to appropriate separate waste disposal plants or to dealers that provide similar service. Separate waste disposal of electrical and electronic appliances prevents possible negative effects on the environment and human health resulting from inadequate disposal, and also allows for recovering and recycling the materials comprising the appliances to ensure significant saving in terms of energy and resources. The separate disposal obligation is underlined by the crossed-out dustbin symbol appearing on the product. Illegal disposal of the product by the user shall determine the application of the administrative sanctions defined by the regulations in force.



improve your life

www.argoclima.com